DTC	21	VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION

DTC	23	VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION

CIRCUIT DESCRIPTION

1KZ–TE: See page 05–370.
1KD–FTV: See page 05–512.

DTC No.	DTC Detection Condition	Trouble Area
21 23	No vehicle speed sensor signal to ECM under following conditions (a) and (b): (2 trip detection logic) (a) Park/neutral position switch is OFF (b) Vehicle is being driven	• Combination meter assy • Vehicle speed sensor • Vehicle speed sensor circuit • ECM

WIRING DIAGRAM

1KZ–TE: See page 05–370.
1KD–FTV: See page 05–512.

INSPECTION PROCEDURE

1KZ–TE: See page 05–370.
1KD–FTV: See page 05–512.