THERMOSTAT (5L–E)

16087–02

REPLACEMENT

1. DRAIN ENGINE COOLANT (See page 16–18)

2. REMOVE WATER OUTLET

(a) Remove the water outlet and radiator inlet hose with the 3 bolts.

3. REMOVE THERMOSTAT

4. INSTALL THERMOSTAT

(a) Install a new gasket.

(b) Install the thermostat.

5. INSTALL WATER OUTLET

(a) Install the water outlet and the radiator inlet hose with the 3 bolts.

Torque: 19 N·m (195 kgf·cm, 14 ft·lbf)

6. ADD ENGINE COOLANT (See page 16–18)

7. CHECK FOR ENGINE COOLANT LEAKS (See page 16–18)