STARTER ASSY (5L–E)

190HY–01

REPLACEMENT

1. REMOVE STARTER ASSY

(a) Disconnect the starter connector.
(b) Remove the terminal cap.
(c) Remove the nut, and disconnect the 30 terminal.
(d) Remove the 2 bolts and starter.

2. INSTALL STARTER ASSY

(a) Install the starter with the 2 bolts.
Torque: 69 N·m (700 kgf·cm, 51 ft·lbf)
(b) Connect the 30 terminal with the nut.
Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)
(c) Install the terminal cap.
(d) Connect the starter connector.