CHARGING SYSTEM (5L–E)

1900M–09

PRECAUTION

1. **Check that the battery cables are connected to the correct terminals.**
2. **Disconnect the battery cables when the battery is given a quick charge.**
3. **Do not perform tests with a high voltage insulation resistance tester.**
4. **Never disconnect the battery while the engine is running.**
5. **Check that the charging cable is tightened on terminal B of the generator and the fuse box.**
6. **Do not check whether the generator or not with connecting terminal F to the other terminal.**