GLOW PLUG ASSY (5L–E)

190HZ–01

REPLACEMENT

1. **REMOVE INTAKE PIPE**
2. **REMOVE GLOW PLUG NO.1 CONNECTOR**

(a) Remove the vehicle's side wire harness, glow plug screw grommets and nuts, and disconnect the glow plug connector No.1

3. **REMOVE GLOW PLUG ASSY**

(a) Using a 12 mm deep socket wrench, remove the 4 glow plugs.

4. **INSTALL GLOW PLUG ASSY**

(a) Using a 12 mm deep socket wrench, install the 4 glow plugs.

Torque: 13 N·m (130 kgf·cm, 10 ft·lbf)

5. **INSTALL GLOW PLUG NO.1 CONNECTOR**

Torque: 1 N·m (10 kgf·cm, 9 in.·lbf)

6. **INSTALL INTAKE PIPE (See page 10–19)**