GLOW PLUG ASSY (1KZ–TE)

190HV–01

REPLACEMENT

1. REMOVE INTERCOOLER ASSY (See page 13–11)

2. REMOVE GLOW PLUG ASSY

(a) Remove the 4 grommets.

(b) Remove the 4 nuts and glow plug connector.

(c) Remove the 4 glow plugs.

3. INSTALL GLOW PLUG ASSY

(a) Install the 4 glow plugs.

Torque: 13 N·m (130 kgf·cm, 10 ft·lbf)

(b) Install the glow plug connector with the 4 nuts.

(c) Install the 4 grommets.

4. INSTALL INTERCOOLER ASSY (See page 13–11)