610BK–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver side seat belt warning lamp does not light up	1. Fuse	–
	2. IG1 relay	–
	3. Combination meter	71–25
	4. Airbag sensor assembly center	60–50
	5. Front seat inner belt assembly LH	61–3
	6. Wire harness	–
Passenger side seat belt warning lamp does not light up	1. Fuse	–
	2. IG1 relay	–
	3. Passenger side seat belt warning lamp assy	05–1582
	4. Front seat inner belt assembly RH	61–3
	5. Wire harness	–