
610BF–01

DISPOSAL

HINT:


When scrapping vehicles equipped with a seat belt pretensioner or disposing of a front seat outer belt (with seat belt pretensioner) always first active the seat belt pretensioner in accordance with the procedure described below. If any abnormality occurs in the seat belt pretensioner operation, contact the SERVICE DEPT. of the DISTRIBUTOR. When disposing of a front seat outer belt assy (with seat belt pretensioner)that was activated in a collision, follow the same procedure listed in step 1–(e) in ”DISPOSAL”.



CAUTION:

- **Never dispose of a front seat outer belt assy with an inactivated pretensioner.**
- **The seat belt pretensioner produces a sizeable exploding sound when it activates, so perform the operation outdoors so that it will not be a nuisance to nearby residents.**
- **When activating a front seat outer belt (with seat belt pretensioner), control operation at least 10 m (33 ft) away from the front seat outer belt.**
- **Use gloves and safety glasses when handling a front seat belt with activated pretensioner.**
- **Always wash your hands with water after completing activation.**
- **Do not apply water, etc. to a front seat outer belt with an activated pretensioner.**
- **When activating the seat belt pretensioner, always use the specified SST (SRS airbag deployment tool). Perform operation in a place away from electrical interference.**


  SST 09082–00700



1. DISPOSE OF FRONT SEAT OUTER BELT ASSY RH (WHEN INSTALLED IN VEHICLE)

HINT:

Check that the battery positive voltage is above 12 V.




(a) Check the functioning of SST.

CAUTION:

When activating the seat belt pretensioner, always use the specified SST.


SST 09082–00700, 09082–00770



(1) Connect the SST red clip to the battery positive (+) terminal and the black clip to the battery negative (–) terminal.

HINT:

Do not connect the yellow connector which will be connected to the seat belt pretensioner.



(2) Press the SST activation switch, and check that the LED of the SST activation switch lights up.

CAUTION:

If the LED lights up when the activation switch is not pressed, the SST may have a malfunction, so definitely do not use the SST.

(b) Disconnect the SST from the battery.

(c) Disconnect the pretensioner connector.

(1) Disconnect the battery negative (–) terminal.

(2) Check the SRS airbag system (See page 60–1).

(3) Remove the front door scuff plate RH (See page 76–58).

(4) Remove the cowl side trim board RH (See page 76–58).


(5) Remove the quarter scuff plate inner RH (See page 76–58).

(6) Remove the rear door scuff plate RH (See page 76–58).

(7) Remove the front door opening trim weatherstrip RH.

(8) Remove the rear door opening trim weatherstrip RH.


(9) Remove the center pillar garnish lower RH (See page 76–58).



(10) Disconnect the pretensioner connector, as shown in the illustration.

(d) Connect SST.

(1) Install the floor anchor of the seat belt.




(2) Connect SST, then connect them to the seat belt pretensioner.

SST 09082–00700, 09082–00770

NOTICE:

To avoid damaging the SST connector and wire harness, do not lock the secondary lock of the twin lock.



(3) Move the SST at least 10 m (33 ft) away from the front of the vehicle.

(4) Close all the doors and windows of the vehicle.

NOTICE:

Take care not to damage the SST wire harness.

(5) Connect the SST red clip to the battery positive (+) terminal and the black clip to the negative (–) terminal.

(e) Activate the seat belt pretensioner.

(1) Confirm that no one is inside the vehicle or within 10 m (33 ft) of the vehicle.

(2) Press the SST activation switch and activate the seat belt pretensioner.

HINT:

The seat belt pretensioner operates simultaneously with the LED light for the SST activation switch.

(f) Dispose of the outer belt assy (with the seat belt pretensioner).

CAUTION:

- **The outer belt is very hot when the seat belt pretensioner is activated the, so leave it untouched for at least 30 minutes after the activation.**
- **Use gloves and safety glasses when handling the outer belt with pretensioner that has been activated.**
- **Always wash your hands with water after completing operation.**
- **Do not apply water, etc. to the outer belt assy with the pretensioner that has been activated.**

HINT:

When scrapping a vehicle, activate the seat belt pretensioner, and then scrap the vehicle with the activated outer belt being installed.

2. DISPOSE OF FRONT SEAT OUTER BELT ASSY RH (WHEN NOT INSTALLED IN VEHICLE)


NOTICE:

- **When disposing of the front seat outer belt (with the seat belt pretensioner) only, never use the customer's vehicle to activate the seat belt pretensioner.**
- **Be sure to follow the procedures listed below when activating the seat belt pretensioner.**

(a) Remove the outer belt assy RH (See page 61–15).


HINT:

Cut the belt near the seat belt retractor.



(b) Check the functioning of SST (See step 1–(a)).

SST 09082–00700, 09082–00770




(c) Connect SST.

(1) Connect SST, then connect them to the seat belt pretensioner.

SST 09082–00700, 09082–00770

NOTICE:

To avoid damaging the SST connector and wire harness, do not lock the secondary lock of the twin lock.



(2) Place the outer belt assy on the ground and cover it with a disc wheel with tire.


NOTICE:

Place the front seat outer belt assy, as shown in the illustration.

(3) Move the SST at least 10 m (33 ft) away from the wheel.

NOTICE:

Take care not to damage the SST wire harness.



(d) Activate the seat belt pretensioner.


(1) Connect the SST red clip to the battery positive (+) terminal and the black clip to the battery negative (–) terminal.

(2) Check that no one is within 10 m (33 ft) of the wheel.

(3) Press the SST activation switch and activate the seat belt pretensioner.

HINT:

The seat belt pretensioner operates simultaneously with the LED light for the SST activation switch.



(e) Dispose of the outer belt assy (with the seat belt pretensioner).

CAUTION:

- **The outer belt assy is very hot when the seat belt pretensioner is activated, so leave it untouched for at least 30 minutes after the activation.**
- **Use gloves and safety glasses when handling the outer belt assy with activated pretensioner.**
- **Always wash your hands with water after completing operation.**
- **Do not apply water, etc. to the outer belt assy with activated pretensioner.**

(1) Remove the wheel and SST.

(2) Place the outer belt assy in a vinyl bag, tie the end tightly and dispose of it in the same way as other general parts.