700OD–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Rear window defogger does not operate (Indicator light ON)	1. DEFOG fuse 2. DEFOF relay 3. Rear window defogger wire 4. Wire harness 5. Instrument Panel junction block assy	68–1 68–1 70–31 – –
Rear window defogger does not operate (Indicator light OFF)	1. DEFOG fuse 2. DEFOG relay 3. Air conditioning control assy 4. Rear window defogger wire 5. Wire harness 6. Instrument Panel junction block assy	68–1 68–1 70–31 70–31 – –
Mirror heater does not operate (Indicator light ON)	1. MIR HEATER fuse 2. MIR HTR relay 3. Outer rear view mirror assy 4. Wire harness 5. Instrument Panel junction block assy	68–1 68–1 70–31 – –
Mirror heater does not operate (Indicator light OFF)	1. MIR HEATER fuse 2. MIR HTR relay 3. Outer mirror heater switch assy 4. Outer rear view mirror assy 5. Wire harness 6. Instrument Panel junction block assy	68–1 68–1 70–31 70–31 – –