CLUTCH SWITCH ASSY

8202U–01

REPLACEMENT

1. **REMOVE INSTRUMENT PANEL UNDER COVER SUB–ASSY NO.1 (See page 71–13)**
2. **REMOVE CLUTCH SWITCH ASSY**

(a) Disconnect the connector.

(b) Loosen the nut and remove the clutch switch assy.