
WATER PUMP ASSY (1KD–FTV)

160HZ–01

INSPECTION



1. INSPECT WATER PUMP ASSY

(a) Visually check the water hole for coolant leakage.

If leakage is found, replace the water pump.

(b) Turn the pulley and check that the water pump bearing moves smoothly and quietly.

If necessary, replace the water pump.