5. PROCEDURES NECESSARY WHEN CABLE IS DISCONNECTED/RECONNECTED TO BATTERY TERMINAL

(a) THE WORK LIST:

(1) Each inspection procedure refers to the TOYOTA Repair Manual.

Necessary Procedure	Effect or Inoperative Function when Necessary Procedure is not Performed
Adjust parking assist monitor system	Calibration

NOTICE:

- After the battery is reconnected, be sure to wait 10 seconds or more before attempting to start the engine. The engine may not start immediately after the battery is reconnected.
- w/ Navigation System (for HDD):
  After the ignition switch is turned off, the HDD navigation system requires approximately a minute to record various types of memory and settings. As a result, after turning the ignition switch off, wait a minute or more before disconnecting the cable from the negative (–) battery terminal.