■ FAIL-SAFE

The following measures are taken as fail-safe when any malfunction is detected by the windshield wiper ECU.

Trouble Area	Condition
Wiper Motor Malfunction	Stops the operation of the rain sensing function.
Communication Signal Malfunction	Rain Sensor: • Continuously performs a wiper operation prior to occurrence of a malfunction. • Switches to the intermittent operation if a malfunction of the rain sensor is detected when the power source is switched from IG-OFF to IG-ON or the wiper switch is in AUTO position.
	Wiper Switch: Continuously perform a wiper operation prior to occurrence of a malfunction.
	Main body ECU, ECM and combination meter: Continuously perform the LO operation.

■ DIAGNOSIS

- If the windshield wiper ECU detects a malfunction in the washer system, it stores 5-digit DTC (Diagnostic Trouble Code) in memory.
- When the rain sensor detects a malfunction, it stores 5-digit DTC (Diagnostic Trouble Code) in memory.
- The 5-digit DTC can be read by connecting an intelligent tester II to the DLC3.