■SLIDING ROOF OPEN WARNING

1. Optitron Display Type Combination Meter

When the engine switch is changed from on (IG) to off and the driver door is opened when the sliding roof is open, the sliding roof ECU turns on the master warning light and sounds the buzzer in the combination meter assembly. Then, a warning message appears on the multi-information display.

Warning Condition		The warning is activated if all of the following conditions are met: • Sliding roof is fully closed. • Engine switch off. • Driver door is closed.
Combination Meter Assembly	Multi-information Display	 080BE124TE
	 0150BE35C	Blinks
	Buzzer	Sounds
Warning Stop Condition		The warning is stopped when one of the following conditions is met: • Approximately 8 seconds have elapsed after the warning condition is detected. • Sliding roof is fully closed. • Engine switch on (IG). • Driver door is closed.

BE

2. Analog Type Combination Meter

When the engine switch is changed from on (IG) to off and the driver door is opened when the sliding roof is open, the siding roof ECU sounds the buzzer in the combination meter assembly.

Warning Condition	The warning is activated if all of the following conditions are met: • Sliding roof is not fully closed. • Engine switch off. • Driver door is opened.
Buzzer	Sounds
Warning Stop Condition	The warning is stopped when one of the following conditions is met: • 8 seconds have elapsed after the warning condition is detected. • Sliding roof is fully closed. • Engine switch on (IG). • Driver door is closed.