Parking Assist Monitor Mode

- The parking assist monitor mode shows the conditions in the rear of the vehicle.
- In the parking assist monitor mode, the screen displays as shown in the illustration below:



19UBE137I

Warning Message

A warning message appears at the bottom, side or center of the screen under the conditions listed below. The warning message appears in the language that has been selected by the language selector of the navigation screen display.

▶ Messages Appearing at Bottom or Side of Screen ◀

Warning Message	Outline
Check surroundings for safety	This message always appears during system operation.
Guidance Unavailable	This message is displayed when an error in the steering angle sensor occurs.

■ FAIL-SAFE

The table below indicates the conditions of detecting malfunctions in the components of this system:

Malfunctioning Parts	Detection Items	Function
Steering Angle Sensor	● Transmission of sensor malfunction signal ● Open circuit in sensor signal ● Communication malfunction between the steering angle sensor and parking assist ECU	Displays “Guidance Unavailable”
Television Camera Assemblies	Transmission of television camera malfunction signal	Stops signal reception and displays a dark screen
Parking Assist ECU	Malfunction of parking assist ECU	Stops system operation

■ DIAGNOSIS

The multi-terrain monitor system is equipped with a diagnosis function which can display the service menus. The method for entering the service menu screen is the same as the method used for the multi display. For details, refer to the Repair Manual.