■ DIAGNOSIS

1. DTC Output

- If the seat belt control ECU detects a malfunction in the pre-crash safety system, it stores a 5-digit Diagnostic Trouble Code (DTC) in memory.
- The 5-digit DTC can be read by connecting an intelligent tester II to the DLC3.

  For details, see the Repair Manual.