





(BAT)
25A
EFI
MAIN
NO. 1
2
7 1S
8 1S
EFI MAIN
NO. 1
Relay
11 1S
4 1S
(IG)
10A
ENG–IG2
NO. 1
2
7 1P
(BAT)
10A
ETCS
2
1
36 CA3
B
P
P
V
L
B
6 A
MREL
1 A
BATT
4 A
IGSW
104 B
+BM
A38(A), C45(B)
ECM
+B
+B2
E1
ME01
E02
E05
E01
E04
EC
2 A
3 A
81 B
18 B
43 B
46 B
41 B
23 B
52 A
B
B
W–B
W–B
W–B
BR
W–B
W–B
W–B
W–B
B
7
A75
Junction
Connector
A5
C1
C12
A4



A31
Accelerator Pedal Sensor Assembly
VPA
VPA2
VCPA
VCP2
EPA
EPA2
6
3
4
1
5
2
R
GR
L
V
W
BE
53 A
56 A
55 A
58 A
54 A
57 A
C3
Throttle Body Assembly
VC
E2
VTA
VTA2
M+
M–
5
3
6
4
2
1
P
B
R
P
R
G
(Shielded)
BR
125 B
124 B
126 B
101 B
20 B
19 B
42 B
VCTA
ETA
VTA1
VTA2
M+
M–
GE01
A38(A), C45(B)
ECM
SFTU
SFTD
S
39 A
47 A
27 A
V
L
W
35 EA3
34 EA3
36 EA3
(IG)
10A
ECU–IG
NO. 2
12 2J
B
2
1
SFTU
SFTD
E
IG
S
E52
Transmission Control Switch
5
3
7
W–B
B
B
E4


V9(C)
Center Differential Lock Switch
ECT Switch
P
2ND
E22
DLC3
TC
TAC
13
9
V
W
76 EA3
74 EA3
V
W
43 A
37 A
TC
TACH
6 C
8 C
GR
P
20 VE5
6 VE5
GR
P
37 EA3
38 EA3
GR
P
13 A
12 A
PWR
SNWI
A38(A), C45(B)
ECM
CCS
ECCS
60 A
59 A
L
BR
32 EA3
25 EA3
BE
BR
W
12 B
1 B
2 B
DIST
CCS
ECC
E122(B), z37(C), z73(D)
Spiral Cable
Sub–Assembly
7 D
4 D
3 C
4 C
ON–OFF
+ RES
– SET
CANCEL
Distance
Control
Steering Pad Switch RH
z73(D)
Steering Pad Switch
z37(C)
Cruise Control Main Switch
B
B
W


(IG)
10A
ENG–IG2
NO. 2
2
8 1R
A80(A), A81(B), A82(C)
Transmission Control ECU Assembly
IGSW
CAN+
CAN–
+B
21 A
1 C
2 C
10 A
B
R
W
B
10 A
18 A
CANP
CANN
A38(A), C45(B)
ECM
SPD
CANL
CANH
STP
ST1–
D
44 A
19 A
11 A
7 A
8 A
49 B
L
W
V
R
P
P
75 EA3
L
P
P
R
V
W
L
B
W
W



A80(A), A81(B), A82(C)
Transmission Control ECU Assembly
EC
GND
E2
THO1
SLU–
SLU+
SLT–
SLT+
SL5–
SL5+
7 C
1 A
24 A
23 A
6 A
7 A
4 A
5 A
3 B
4 B
W–B
G
B
L
R
LG
B
R
W
1 CA3
17 CA3
16 CA3
3 CA7
2 CA7
17 CA7
16 CA7
20 CA7
10 CA7
BR
G
L
R
LG
B
R
W
2
1
6
5
12
11
22
21
OT–
OT+
SLU–
SLU+
SLT–
SLT+
SL5–
SL5+
O
O
BR
G
L
G
BR
W
C171
Electronically Controlled Transmission Solenoid
P
P
R
V
W
L
W
4
A75
Junction
Connector
A5
C12


A80(A), A81(B), A82(C)
Transmission Control ECU Assembly





C171
Electronically Controlled Transmission Solenoid






A80(A), A81(B), A82(C)
Transmission Control ECU Assembly
SPD
C
18 C
6 C
L
P
59 EA1
3 A
9 B
8 B
A37(A), C44(B)
Junction
Connector
(IG)
(IG)
10A
BKUP
LP
10A
ECU–IG
NO. 2
2
2
11 2H
24 2H
G
G
27 CA6
48 CA6
G
G
1
6
RB
IG
C
C24
Park/Neutral Position Switch
4
P
P
P
P
R
R
V
V
W
W
L
L
W
W



(IG)
10A
IG2
NO. 1
22
2H
(BAT)
10A
STOP
2
1
L
B
5
1
L
L
B
B
A73
Stop Light
Switch Assembly
L
L
GND
4
2
3
P
R
W-B
R
R
P
R
V
W
W-B
V
W
L
W
L
W
A2


A39
Stop Light Control Relay Assembly
STP
GND
OUT
+B
(IG)
10A
ENG–IG
NO. 1
STP LP OPE
Relay
W–B
A24(A)
Skid Control ECU with
Actuator Assembly
STP
STP2
STPO
CANL
CANH
FL+
FL–
FR+
FR–
RL+
RL–
RR+
RR–
SP1
Speed Sensors
EA1
AA1
A4



*4 : w/ VGRS
*5 : w/o VGRS
E133 Junction Connector
E135 Junction Connector
E145 Network Gateway ECU
E47(A) Center Airbag Sensor Assembly
Yaw Rate Sensor
CANH
CANL
CA4H
CA4L
CA5L
CA5H
E121(A), E163(B) Steering Sensor
EE2
EA3
W
L
SB
GR
V
BE
B


(BAT)
(IG)
10A
MPX–B
NO. 2
5A
METER
2
1
49
2I
V
46
EA1
BE
V
E119(A)
Combination Meter Assembly
21
A
22
A
B
IG+
Power
Supply
Circuit
+B
IG+
Master
CRUISE
SET
Radar Cruise
TFT
Buzzer
SUB
IG
One Step
Dim
One Step
Dim
CAN
INPUT
SI
+S
CANL
CANH
ET
5
A
6
A
40
A
39
A
20
A
W
L
W
BE
BR
3
EA1
67
EA3
BR
19
A
14
B
A37(A), C44(B)
Junction
Connector
V
W
BE
SB
B
L
W
SB
B
W
BR
C1



* 7 : w/ Pre–Crash Safety System Heater
(IG)
10A
ECU–IG
NO. 2
(IG)
10A
ECU–IG
NO. 3
24 2H
12 2J
33 2I
G
B
B (*7)
B (*7)
16 RE3
10 RE1
B (*7)
1
IG1
HTR
2
V (*7)
R26
Forward Recognition with
Heater Hood Sub–Assembly
A72
Millimeter Wave
Radar Sensor Assembly
8
7
1
11
5
IGB
IGB
HTR
CA1N
CA1P
SGND
CA2L
CA2H
CA1P
CA1N
GND
CANL
CANH
R20
Forward
Recognition Camera
1
2
3
5
6
10
12
6
BR
B
L
B
P
BR
P
R
50 EA2
49 EA2
12 RE1
15 RE3
5 RE3
B
P
P
R
P
W
16
6
17
7
E174
Junction
Connector
15
5
L
B
SB
B
SB
B
W
W
2
A75
Junction
Connector
A5
E5
P
W
B
G


(IG)
5A
ECU–IG
NO. 6
5
3C
P
W
B
G
P
P
2
IG1
BZ
E5
Skid Control
Buzzer Assembly
1
L
3
W
P
P
8
9
7
CA1P
CA1N
B
BZ
E164
Driving Support
ECU Assembly
CA2H
CA2L
SPSW
GND
10
11
23
28
BR
9
RE3
8
RE3
G
B
L
B
W
9
19
4
14
E151
Junction
Connector
6
16
5
15
L
B
SB
B
33
EA2
34
EA2
L
B
L
B
SB
B
W
BR
E4


A 24
Black




A 31
Black




A 37
Blue




A 38
Black




A 39
Black




A 72
Black




A 73
Gray




A 75
Black




A 80
White




A 81
White




A 82
White




C 3
Black




C 24
Gray




C 44
Blue




C 45
Black




C171
Gray




E 5
Blue




E 22
White




E 47
Yellow




E 52
White




E119
Black




E121
White




E122
Black




E133
White




E135
White




E145
Black




E151
White




E163
White




E164
White




E174
White




R 20
Gray




R 26
Black




V 9
White




z 37
White




z 73
Black




1P
White




1R
Black




1S
White




2H
White




2I
White




2J
White




3C
White




AA1
Gray




CA3
White




CA6
White



CA7
White




EA1
White




EA2

White





Gray



EA3


White






EE2


White




RE1

White




RE3
Blue
1
11
2 3 4 5 6 7 8 9
12 13 14 15 16 17 18 19
10
20
10
20
9 8 7 6 5 4 3 2
19 18 17 16 15 14 13 12
1
11


VE5
White
1 2 3 4 5 6 7 8 9 10 11 12 13 14
15 16 17 18 19 20 21 22 23 24 25 26
14 13 12 11 10 9 8 7 6 5 4 3 2 1
26 25 24 23 22 21 20 19 18 17 16 15