ABBREVIATIONS

The following abbreviations are used in this manual.

A/C	=	Air Conditioner
BACS	=	Boost Altitude Compensational Stopper
COMB.	=	Combination
DIFF.	=	Differential
DLC3	=	Data Link Connector 3
ECU	=	Electronic Control Unit
EFI	=	Electronic Fuel Injection
EGR	=	Exhaust Gas Recirculation
E–VRV	=	Electronic Vacuum Regulating Valve
FL	=	Fusible Link
G.C.C.	=	Gulf Cooperation Council
ISC	=	Idle Speed Control
LH	=	Left–Hand
LHD	=	Left–Hand Drive
R/B	=	Relay Block
RH	=	Right–Hand
RHD	=	Right–Hand Drive
SW	=	Switch
TEMP.	=	Temperature
VSV	=	Vacuum Switching Valve
w/	=	With
w/o	=	Without
2WD	=	Two Wheel Drive Vehicles
4WD	=	Four Wheel Drive Vehicles

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.