H PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Magnetic Clutch	90980–11271
A 2	A/C Water Temp. SW	–
A 3	Air Cleaner Warning SW	90980–11025
A 5	Alternator (1FZ–FE, 1HZ RHD)	90980–09187
	Alternator (1HZ Except RHD)	90980–09201
A 6	Alternator	90980–11349
A 7	A/C Amplifier	90980–10045
A 8	A/C Cut Relay (Water Temp.)	90980–10142
A 9	A/C Dual Pressure SW	90980–10216
A10	A/C Thermistor	90980–10214
B 1	Back–Up Light SW (1FZ–FE)	90980–11051
	Back–Up Light SW (1HZ)	90980–11250
B 2	Brake Fluid Level SW	90980–11207
B 3	Back Door Courtesy SW	–
B 5	Back Door Lock Motor	
B 6	Buckle SW	90980–10906
B 7	Back Buzzer	90980–10887
C 9	Cigarette Lighter	90980–10216
C10	Circuit Opening Relay	90980–10224
C11	Clock	90980–10171
C12	Combination Meter	90980–11113
C13	Combination Meter	90980–11114
C14	Combination Meter	90980–11115
C15	Combination SW	90980–11478
C16	Combination SW	90980–11479
C17	Center Diff. Lock Control Motor	90980–11024
C18	Center Diff. Lock Control Relay	90980–10801
C19	Center Diff. Lock Indicator SW	90980–11250
C20	Center Diff. Lock Indicator SW	90980–10243
C21	Check Connector	–
C24	Camshaft Position Sensor	90980–10947
C25	Crankshaft Position Sensor	90980–11016
D 2	Daytime Running Light Relay or Short Connector	90980–10807
D 3	Diff. Lock ECU	90980–10848
D 9	Diode (Light Reminder)	90980–10962
D10	Diode (Rear Fog Light)	90980–11071
D12	Door Courtesy SW Front LH	90980–10433
D14	Door Courtesy SW Front LH	
D15	Door Courtesy SW Front RH	
D18	Door Key Lock and Unlock SW (Driver's Side)	–
D19	Door Lock Control Relay	
D20	Door Lock Control SW	

Code	Part Name	Part Number
D21	Door Lock Motor (Driver's Side)	–
D22	Door Lock Motor (Front Passenger's Side)	
D26	Diff. Lock Control SW	90980–10631
D27	Detection SW (Transfer Neutral Position)	90980–10247
D28	Diode (Seat Belt Warning) (1FZ–FE)	90980–10962
	Diode (Seat Belt Warning) (1HZ)	90980–11608
D29	DLC3	90980–11665
E 1	EFI Main Relay	90980–11139
E 2	EFI Water Temp. Sensor	90980–10737
E 6	Engine Oil Level Sensor (1FZ–FE RHD)	90980–11235
	Engine Oil Level Sensor (1HZ)	90980–10532
E 9	Emission ECU	90980–11391
E10	Emission ECU	90980–11390
E11	Engine ECU	
E12	Engine ECU	90980–11391
E16	Engine ECU	90980–11392
F 6	Front Fog Light LH	–
F 7	Front Fog Light RH	
F 8	Front Side Turn Signal Light LH	90980–11142
F 9	Front Side Turn Signal Light RH	
F14	Front Washer Motor	90980–10214
F15	Front Wiper Motor	90980–11194
F19	Fuel Cut Solenoid and Pick–Up Sensor	90980–11157
F21	Fuel Heater	90980–10928
F27	Fusible Link Box	99141–12006
F33	Front Blower Motor	90980–10214
F34	Front Blower Resistor	90980–10171
F36	Front Fog Light SW	90980–10214
F37	Front Heater Blower SW	90980–10209
F38	Front Wiper Relay	90980–10799
F42	Fuse Block No.1	82610–60070
F43	Fuel Pump	90980–11142
F44	Fuel Sender (Front)	90980–11016
F46	Front Diff. Lock Control Motor	90980–11194
F47	Front Diff. Lock Position SW	90980–11250
F48	Front Turn Signal Light and Clearance Light LH	90980–11016
F49	Front Turn Signal Light and Clearance Light RH	
F50	Fuel Cut Solenoid and Crankshaft Position Sensor	90980–11157
F52	Fuel Pump Relay	90980–10939
F53	Fuel Pump Resistor	90980–10581

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number
F54	Fuel Solenoid Valve 1	90980–10901
F55	Fuel Solenoid Valve 2	
F57	Fusible Link Box	90980–10122
F58	Fusible Link Box	99141–12005
F59	Fusible Link Box	90980–10114
F61	Fuel Pump (Sub)	90980–11142
F63	Fuel Sender (Rear) (Long Body Type, Pick–Up Body Type)	90980–10500
	Fuel Sender (Rear) (Short Body Type, Middle Body Type)	90980–11293
F64	Fuel Pump Select Relay	90980–10173
F65	Fuel Sediment SW 1	90980–11003
F66	Fuel Sediment SW 2	
F67	Fuel Tank Changeover SW	90980–10797
G 1	Glow Plug	99141–13004
G 2	Glow Plug Relay (Main)	90980–11569
H 1	Headlight Beam Level Control Actuator LH	90980–10891
H 2	Headlight Beam Level Control Actuator RH	
H 3	Headlight Cleaner Motor	90980–10157
H 4	Headlight Cleaner Relay	90980–10550
H 5	Headlight LH	99149–53030
H 6	Headlight RH	
H 7	Horn (High)	90980–10092
H 8	Horn (High)	90980–10786
H 9	Horn (High)	
H10	Horn (Low)	90980–10092
H11	Horn (Low)	90980–10786
H12	Horn (Low)	
H16	Headlight Beam Level Control SW	–
H17	Headlight Cleaner SW	90980–10362
H18	Heater Illumination	90980–10039
H21	High Mounted Stop Light	–
I 4	Injector No.1	90980–11153
I 5	Injector No.2	
I 6	Injector No.3	
I 7	Injector No.4	
I11	Ignition SW	90980–10862
I15	Interior Light Front	–
I19	Injector No.5	90980–11153
I20	Injector No.6	
I21	ISC Valve	90980–11145
I22	Interior Light Front	90980–10183
I23	Interior Light Front	90980–10182

Code	Part Name	Part Number
I24	Interior Light Rear	–
I25	Interior Light Rear	
I26	Ignition Coil and Igniter No.1	90980–11150
I27	Ignition Coil and Igniter No.2	
I28	Ignition Coil and Igniter No.3	
I29	Intake Air Temp. Sensor	90980–11163
J 1	Junction Connector No.1	82670–14030
J 2	Junction Connector No.2	
J 3	Junction Connector No.3	
J 4	Junction Connector No.4	90980–10803
K 1	Knock Sensor 1	90980–11166
K 2	Knock Sensor 2	
L 2	Light Reminder Relay	90980–10171
L 3	License Plate Light	–
L 4	License Plate Light LH	90980–11142
L 5	License Plate Light RH	
L 6	License Plate Light LH	
L 7	License Plate Light RH	
M 2	Moon Roof Control Relay	90980–10043
M 3	Moon Roof Control SW and Personal Light	–
M 5	Moon Roof Limit SW	
M 7	Moon Roof Motor	
N 2	Noise Filter (Ignition)	90980–10843
N 5	No.1 Instrument Cluster Illumination	90980–10906
O 1	Oil Pressure Sender (1FZ–FE)	90980–11363
	Oil Pressure Sender (1HZ)	90980–10703
P 2	Pre–Heating Timer	90980–10803
P 3	Parking Brake SW	90980–10871
P 5	Power Window Master SW	–
P 7	Power Window Motor (Driver's Side)	
P 8	Power Window Motor (Front Passenger's Side)	
P11	Power Window SW (Front Passenger's Side)	
P12	Power Window SW (Front Passenger's Side)	
P15	Power Outlet	90980–10990
P16	Power Window Control Relay	–
R 1	Radio and Player	90980–10997
R 2	Radio and Player	90980–10996
R 3	Rear Fog Light Relay	90980–10221
R 5	Rear Fog Light SW (Europe)	90980–11533
	Rear Fog Light SW (General)	90980–10601

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile–Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile–Prospekt–Nachtrichten" (herausgegeben durch die Teile–Engineering–Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.

H PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
R 7	Rear Window Defogger SW	90980–10216
R 8	Rear Wiper and Washer SW	90980–10127
R15	Rear Blower Motor and Resistor	90980–10216
R16	Rear Combination Light LH	90980–11296
R17	Rear Combination Light LH	90980–10988
R18	Rear Combination Light RH	90980–11296
R19	Rear Combination Light RH	90980–10988
R23	Rear Heater Blower SW	90980–10171
R24	Rear Washer Motor	90980–10214
R25	Rear Window Defogger	–
R26	Rear Window Defogger	
R27	Rear Window Defogger	
R28	Rear Window Defogger	
R29	Rear Wiper Motor	
R31	Rear Wiper Relay	90980–10173
R36	Rheostat	90980–10490
R37	Rear Combination Light LH	90980–11001
R38	Rear Combination Light LH	90980–10942
R39	Rear Combination Light RH	90980–11001
R40	Rear Combination Light RH	90980–10942
R41	Rear Diff. Lock Position SW	90980–11250
R42	Rear Diff. Lock Control Motor	90980–11290
R43	Rear Fog Light	90980–10887
R44	Remote Control Mirror SW	90980–10043
R45	Remote Control Mirror LH	–
R46	Remote Control Mirror RH	
R47	Rear Combination Light LH	90980–11013
R48	Rear Combination Light RH	
S 2	Starter (1FZ–FE)	90980–11400
	Starter (1HZ)	90980–11184
S 3	Starter	90980–09507
S 4	Starter Relay	90980–11139
S 6	Seat Belt Warning Relay	90980–10801
S11	Speaker Front LH	90980–10298
S12	Speaker Front RH	
S14	Stop Light SW	90980–11118
S16	Speaker Rear LH	–
S17	Speaker Rear RH	
S22	Speed Sensor (Combination Meter)	90980–11143
S23	Sub Fuel Pump Forcing Driving Relay	90980–10221
T 2	Throttle Position Sensor	90980–11261
	Throttle Position Sensor (1HZ)	90980–11016
T 4	Transfer Control Solenoid (2WD)	90980–11149
T 5	Transfer Control Solenoid (4WD)	90980–11156

Code	Part Name	Part Number
T12	Transfer Control SW	90980–10041
T14	Trailer Socket	90980–10214
T15	Trailer Socket	90980–10213
T16	Trailer Socket	90980–10216
T17	Transfer L4 Position SW	90980–11250
T18	Transfer L4 Position SW	90980–10157
T21	Trailer Socket	90980–10173
V 1	Vacuum SW (Brake)	90980–11252
V 4	VSV (A/C Idle–Up)	90980–11156
V 6	E–VRV (EGR)	90980–11162
V13	Vacuum Sensor	90980–10845
V14	VSV (BACS)	90980–11156
V15	VSV (EGR Cut)	
V19	Variable Resistor	90980–10902
W 1	Water Temp. Sender	90980–11428
W 2	Water Temp. Sensor (Glow)	90980–10737
W 4	Winch Main Relay	–
W 5	Winch Main Relay	
W 6	Winch Main Relay	
W 7	Winch Motor and Magnetic SW	
W 8	Wiper Lock Relay	90980–10173
W 9	Wiper Lock SW	90980–10182
W10	Winch Motor and Magnetic SW	–
W11	Water Temp. Sensor (Emission Control)	90980–10737

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using “Parts Catalog News” (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d’un connecteur ou d’une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à ”Parts Catalog News” (publié par le Département de la Gestion de l’Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a ”Parts Catalog News” (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile–Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der ”Teile–Prospekt–Nachtrichten” (herausgegeben durch die Teile–Engineering–Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.