TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

See page / Parts Name / Trouble	AC-18	AC-16	AC-20	BE-10	BE-10	BE-10	AC-50	AC-41	BE-61
	Inspect Volume of Refrigerant	Inspect Refrigeration System with Manifold Gauge Set	Inspect Drive Belt Tension	Fusible Link	Medium Current Fuse	Fuse	Pressure Switch	Thermistor	Water Temp. Switch
No blower operation				1	2				
No blower control									
No air flow mode control									
No air inlet control									
Insuficient flow of cool air									
Insuficient flow of warm air									
No cool air comes out	2	3	4			1	5	11	
Cool air comes out intermittently	1	2	3					5	
Cool air comes out only at high engine speed	2	3	1						
Insufficient cooling	1	2	3					11	6
No warm air comes out									
Air temp. control not functioning									
No engine idle up when A/C switch on									

TROUBLESHOOTING (Cont'd)

Heater Relay AC-53	Blower Resistor AC-52	Blower Motor AC-52	A/C Control Assembly AC-47	A/C Amplifier AC-55	Compressor AC-22	Condenser AC-37	Evaporator AC-40	Expansion Valve AC-45	Magnetic Clutch AC-25	Receiver AC-38	Water Valve AC-48	Heater Radiator —	A/C Idle Up VSV AC-54	Wiring or Wiring Connection AC-6
3	6	5	4											7
	2		1											3
			1											2
			1											2
1	3	2					4							5
1	3	2										4		5
			9	10	7				6		8			
				4				6						7
					5	4								
				10	9	4	12	13	8	5	7			
			2								1	3		4
			2								1			3
				2									1	3