
# BLOWER SWITCHES

## Front Heater Blower Switch

### INSPECTION OF BLOWER SWITCH

#### INSPECT SWITCH CONTINUITY




O-8-2


| Terminal / Switch position | 1 | 2 | 3 | 4 | 5 | 6 |
|---|---|---|---|---|---|---|
| OFF | | | | | | |
| I | | ○ | ○ | ○ | | |
| II | | ○ | ○ | | ○ | |
| III | | ○ | ○ | | | ○ |
| IV (HI) | ○ | ○ | ○ | | | |

If continuity is not as specified, replace the switch.

## Rear Heater Blower Switch

### INSPECTION OF BLOWER SWITCH

#### INSPECT SWITCH CONTINUITY




H-4-2

| Terminal / Switch position | 1 | 2 | 3 | 4 |
|---|---|---|---|---|
| HI | ○ | ○ | | ○ |
| OFF | | | | |
| LO | | ○ | ○ | ○ |

If continuity is not as specified, replace the switch.