PRECAUTION

Care must be taken to replace parts properly because they may affect the performance of the steering system and result in a driving hazard.

TROUBLESHOOTING

Problem	Possible cause	Remedy	Page
Hard steering	Tires improperly inflated	Inflate tires to proper pressure	A-15
	Insufficient lubricant	Lubricate suspension and steering linkage	
	Excessive caster	Check front wheel alignment	SA-3
	Steering system joints worn	Replace steering system joints	SR-72, 76
	Steering column binding	Inpsect steering column	SR-4
	Steering gear out of adjustment or broken	Adjust or repair steering gear	SR-20, 62
	Power steering belt loose	Adjust belt	SR-33
	Fluid level in reservoir low	Check reservoir	SR-34
	Power steering unit faulty	Check power steering unit	SR-38, 62
Poor return	Tires improperly inflated	Inflate tires to proper pressure	A-15
	Insufficient lubricant	Lubricate suspension	
	Wheel alignment incorrect	Check front wheel alignment	SA-3
	Steering column binding	Inspect steering column	SR-4
	Steering gear out of adjustment or broken	Adjust or repair steering gear	SR-20, 62
Excessive play	Front wheel bearing worn	Replace front wheel bearing	SA-29
	Main shaft yoke or intermediate shaft yoke worn	Replace main shaft or intermediate shaft	SR-4
	Steering system joints worn	Replace steering system joints	SR-72, 76
	Steering gear out of adjustment or broken	Adjust or repair steering gear	SR-20, 62
Abnormal noise	*Steering linkage loose*	Tighten steering linkage	SR-72, 76
	Steering system joints worn	Replace steering system joints	SR-72, 76
	Steering gear out of adjustment or broken	Adjust or repair steering gear	SR-20, 62