BODY

Torque Specifications

Part tightened	N·m	kgf·cm	ft·lbf
SEAT			
Front Seat			
Seat adjuster × Body	39	400	29
Seat adjuster × Seat	29	300	22
Reclining seat adjuster × Seat cushion	52	530	38
Second Seat			
Seat hinge × Body	39	400	29
Reclining seat adjuster × Seat cushion	52	530	38
Seat inner support × Seat cushion	41	420	30
Seat inner support × Seat lock	43	440	32
Third Seat			
Inner leg × Seat cushion	18	185	13
Striker bar × Body	18	185	13
Outer lock × Seat cushion	41	420	30
Seat adjuster × Seat back (Parallel type)	52	530	38
Seat frame × Body	18	185	13
SEAT BELT			
ELR × Body	5.4	55	48 in.·lbf
Seat belt anchor × Body	43	440	32
FUEL TANK			
Fuel sender gauge set screw	3.9	40	35 in.·lbf
Fuel tank breather set screw	1.5	15	13 in.·lbf
Fuel tank filler pipe lower set screw	3.9	40	35 in.·lbf
Fuel tank front bracket × Body	39	400	29
Drain plug	6.4	65	56 in.·lbf

LUBRICANT

Item	Capacity			Classification
	Liters	US qts	Imp.qts	
Manual transmission oil	2.6	2.7	2.3	API GL-4 or GL-5 SAE 75W-90