TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

See page / Parts Name / Trouble	—	MT-2	—	MT-5	MT-5	MT-5	MT-5, 6	MT-7	MT-6	MT-6	MT-18, 20	MT-18, 20				
	Oil (Level low)	Oil (Wrong)	Oil (Level too higt)	Gasket (Damaged)	Oil seal (Worn or damaged)	O-Ring (Worn or damaged)	Locking ball spring (Damaged)	Shift fork (Worn)	Gear (Worn or damaged)	Bearng (Worn or damaged)	Synchronizer ring (Worn or damaged)	Shifting key spring (Damaged)				
Noise	1	2							3	3						
Oil leakage			1	2	2	3										
Hard to shift or will not shift											2	3				
Jumps out of gear							1	2	3	3						