MT04P–03

INSTALLATION

Installation is in the reverse order of removal (See page MT–11).

HINT:

After installation, do the road test.