IG0FM–01

REPLACEMENT

1. REMOVE CAMSHAFT POSITION SENSOR

(a) Disconnect the sensor connector.

(b) Remove the bolt and sensor.

2. REINSTALL CAMSHAFT POSITION SENSOR

(a) Install the sensor with the bolt.

Torque: 8.0 N·m (80 kgf·cm, 70 in.·lbf)

(b) Connect the sensor connector.