IG0FO–01

REPLACEMENT

1. REMOVE CRANKSHAFT POSITION SENSOR

(a) Disconnect the sensor connector.

(b) Remove the 3 bolts and sensor protector.

(c) Remove the 2 nuts and sensor.

2. REINSTALL CRANKSHAFT POSITION SENSOR

(a) Install the sensor with the 2 nuts.

Torque: 9.0 N·m (90 kgf·cm, 80 in.·lbf)

(b) Install the sensor protector with the 3 bolts.

Torque: 20 N·m (204 kgf·cm, 15 ft·lbf)

(c) Connect the sensor connector.