ABBREVIATIONS

The following abbreviations are used in this manual.

A/C	=	Air Conditioner
ABS	=	Anti−Lock Brake System
ACIS	=	Acoustic Control Induction System
BA	=	Brake Assist
BEAN	=	Body Electronics Area Network
CAN	=	Controller Area Network
DC	=	Direct Current
DLC3	=	Data Link Connector 3
EB	=	Electrical Brake
ECU	=	Electronic Control Unit
EFI	=	Electronic Fuel Injection
EPS	=	Electric Motor Power Steering
ESA	=	Electronic Spark Advance
EVAP	=	Evaporative Emission
HV	=	Hybrid Vehicle
IC	=	Integrated Circuit
INT	=	Intermittent
J/B	=	Junction Block
LH	=	Left−Hand
LHD	=	Left−Hand Drive
MPX	=	Multiplex
PTC	=	Positive Temperature Coefficient
R/B	=	Relay Block
RH	=	Right−Hand
RHD	=	Right−Hand Drive
SOC	=	State of Charge
SPEC.	=	Specification
SRS	=	Supplemental Restraint System
SW	=	Switch
TEMP.	=	Temperature
TRC	=	Traction Control
VSC	=	Vehicle Stability Control
VSV	=	Vacuum Switching Valve
VVT−i	=	Variable Valve Timing−intelligent
w/	=	With
w/o	=	Without

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.