Driver Side J/B (See Page 28)

Fuse		System	Page
7.5A	ACC	Clock	410
		Double Locking	334
		Interior Light	228
		Key Reminder Buzzer	256
		Light Auto Turn Off System	222
		Multi−Display and Audio System (Built−in Amplifier)	436
		Multi−Display and Audio System (Separate Amplifier)	422
		Multiplex Communication System (AVC−LAN Bus)	110
		Multiplex Communication System (BEAN Bus)	102
		Multiplex Communication System (CAN Bus)	106
		Power Window	272
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Remote Control Mirror	414
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
		Theft Deterrent	338
7.5A	AM1	Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Shift Control System	350
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
7.5A	ECU−IG	Brake Control System	386
		Door Lock Control	276
		Double Locking	334
		Engine Control	196
		EPS	378
		Headlight	210
		Interior Light	228
		Key Reminder Buzzer	256
		Light Auto Turn Off System	222
		Luggage Compartment Door Opener	328
		Multi−Display and Audio System (Built−in Amplifier)	436
		Multi−Display and Audio System (Separate Amplifier)	422
		Multiplex Communication System (AVC−LAN Bus)	110
		Multiplex Communication System (BEAN Bus)	102
		Multiplex Communication System (CAN Bus)	106
		Power Window	272
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Radiator Fan and Condenser Fan	456
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302

∗ These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	ECU–IG	Theft Deterrent	338
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
		Wireless Door Lock Control (w/o Smart Entry System)	320
7.5A	IGN	Brake Control System	386
		Combination Meter	448
		Cruise Control	364
		Engine Control	196
		EPS	378
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Shift Control System	350
		SRS	401
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
7.5A	OBD	Engine Control	196
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
7.5A	PANEL	Clock	410
		Taillight and Illumination	238
7.5A	STOP	Brake Control System	386
		Cruise Control	364
		EPS	378
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Shift Control System	350
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
		Stop Light	246
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
10A	A/C(HTR)	Air Conditioner	460
		Rear Window Defogger and Mirror Heater	416
10A	GAUGE	Air Conditioner	460
		Back–Up Light	18
		Brake Control System	386
		Combination Meter	448
		Cruise Control	364
		Engine Control	196
		EPS	378
		Headlight	210
		Key Reminder Buzzer	256
		Luggage Compartment Door Opener	328
		Multi–Display and Audio System (Built–in Amplifier)	436

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	GAUGE	Multi−Display and Audio System (Separate Amplifier)	422
		Power Window	272
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Rear Window Defogger and Mirror Heater	416
		Seat Belt Warning	260
		Shift Control System	350
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
		SRS	401
		Taillight and Illumination	238
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
		Turn Signal and Hazard Warning Light	224
10A	TAIL	Front Fog Light	220
		Headlight Beam Level Control	218
		Rear Fog Light	252
		Taillight and Illumination	238
15A	ECU−B	Air Conditioner	460
		Multi−Display and Audio System (Built−in Amplifier)	436
		Multi−Display and Audio System (Separate Amplifier)	422
		Multiplex Communication System (AVC−LAN Bus)	110
		Multiplex Communication System (BEAN Bus)	102
		Multiplex Communication System (CAN Bus)	106
		Rear Window Defogger and Mirror Heater	416
15A	M/HTR	Rear Window Defogger and Mirror Heater	416
15A	PWR OUTLET	Power Outlet	412
15A	PWR OUTLET FR	Power Outlet	412
15A	RR WIP	Rear Wiper and Washer	268
20A	FR DOOR	Power Window	272
20A	WSH	Front Wiper and Washer	264
		Rear Wiper and Washer	268
25A	ACC−B	Push Button Start System and Hybrid Vehicle Immobilizer System	114
25A	DOOR	Door Lock Control	276
		Double Locking	334
		Luggage Compartment Door Opener	328
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
		Theft Deterrent	338
		Wireless Door Lock Control (w/o Smart Entry System)	320
25A	WIP (Except Australia)	Front Wiper and Washer	264

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
30A	POWER	Power Window	272
30A	WIP (Australia, Singapore, Hong Kong)	Front Wiper and Washer	264
40A	DEF	Rear Window Defogger and Mirror Heater	416

Engine Room R/B or J/B (See Page 22)

Fuse		System	Page
7.5A	P CON MAIN	Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Shift Control System	350
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
10A	ABS MAIN1	Brake Control System	386
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
10A	ABS MAIN2	Brake Control System	386
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
10A	BATT FAN	TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
10A	ETCS	Cruise Control	364
		Engine Control	196
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
10A	HAZ	Turn Signal and Hazard Warning Light	224
10A	H−LP HI LH	Headlight	210
10A	H−LP HI RH	Headlight	210
10A	H−LP LO LH	Headlight	210
10A	H−LP LO RH	Headlight	210
10A	HORN	Horn	408
		Theft Deterrent	338
10A	RR FOG LP	Rear Fog Light	252
15A	ABS MAIN3	Brake Control System	386
15A	AM2	Engine Control	196
		Ignition	192
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Shift Control System	350
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
15A	DOME	Air Conditioner	460
		Back−Up Light	18
		Brake Control System	386
		Clock	410

∗ These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
15A	DOME	Combination Meter	448
		Cruise Control	364
		Door Lock Control	276
		Double Locking	334
		Engine Control	196
		EPS	378
		Headlight	210
		Interior Light	228
		Key Reminder Buzzer	256
		Light Auto Turn Off System	222
		Luggage Compartment Door Opener	328
		Multi−Display and Audio System (Built−in Amplifier)	436
		Multi−Display and Audio System (Separate Amplifier)	422
		Power Window	272
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Rear Window Defogger and Mirror Heater	416
		Seat Belt Warning	260
		Shift Control System	350
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
		SRS	401
		Taillight and Illumination	238
		Theft Deterrent	338
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
		Wireless Door Lock Control (w/o Smart Entry System)	320
15A	EFI	Cruise Control	364
		Engine Control	196
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
15A	FR FOG	Front Fog Light	220
20A	HEV	Cruise Control	364
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Shift Control System	350
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
30A	ABS−1	Brake Control System	386
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
30A	ABS−2	Brake Control System	386
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160

∗ These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
30A	AMP	Multi−Display and Audio System (Separate Amplifier)	422
30A	CDS FAN	Radiator Fan and Condenser Fan	456
30A	P CON MTR	Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Shift Control System	350
30A	PTC HTR1	Air Conditioner	460
30A	PTC HTR2	Air Conditioner	460
30A	RDI	Engine Control	196
		Radiator Fan and Condenser Fan	456
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
40A	HEAD MAIN	Headlight	210
		Light Auto Turn Off System	222
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
40A	HTR	Air Conditioner	460
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160
50A	EPS	EPS	378
50A	PS HTR	Air Conditioner	460
60A	P/I	Engine Control	196
		Ignition	192
100A	DC/DC	Front Fog Light	220
		Interior Light	228
		Light Auto Turn Off System	222
		Power Window	272
		Push Button Start System and Hybrid Vehicle Immobilizer System	114
		Rear Fog Light	252
		Smart Entry System (LHD) and Wireless Door Lock Control (w/ Smart Entry System) (LHD)	284
		Smart Entry System (RHD) and Wireless Door Lock Control (w/ Smart Entry System) (RHD)	302
		Taillight and Illumination	238
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160

Fusible Link Block (See Page 27)

Fuse		System	Page
120A	MAIN	Engine Control	196
		Ignition	192

Fuse Holder (F17 on See Page 57 (LHD) or 67 (RHD))

Fuse		System	Page
30A	ABS	Brake Control System	386
		TOYOTA Hybrid System (LHD)	128
		TOYOTA Hybrid System (RHD)	160

* These are the page numbers of the first page on which the related system is shown.