L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Condenser Fan Motor	90980–10928
A 2	ABS & BA & TRC & VSC Actuator	90980–12297
A 3	ABS Speed Sensor Front LH	90980–11003
A 4	ABS Speed Sensor Front RH	
A 5	Air Flow Meter	90980–11317
A 6	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980–10869
A 7	Airbag Sensor Front LH	90980–11856
A 8	Airbag Sensor Front RH	
A 9	Ambient Temp. Sensor	90980–11070
A10	A/C Control Assembly	90980–12150
A11	A/C Control Assembly	90980–12149
A12	A/C Room Temp. Sensor	90980–11950
A13	A/C Solar Sensor	90980–11918
A14	A/C Thermistor	
A15	ACC Relay	82660–20340
A16	Accel Position Sensor	90980–11858
A17	Air Inlet Control Servo Motor	90980–11909
A18	Air Mix Control Servo Motor	
A19	Air Vent Mode Control Servo Motor	
A20	Airbag Sensor Assembly	90980–12392
A21	Airbag Sensor Assembly	90980–12391
A22	Airbag Sensor Assembly	90980–12390
A23	Airbag Squib (Front Passenger Airbag Assembly No.1)	90980–12224
A24	Airbag Squib (Front Passenger Airbag Assembly No.2)	90980–12219
A25	Airbag Squib (Steering Wheel Pad)	90980–12160
A26	Antenna Amplifier	90980–10871
A27	ABS Speed Sensor Rear LH	90980–11900
A28	ABS Speed Sensor Rear RH	
B 1	Brake Fluid Level Warning SW	90980–11207
B 2	Blower Motor	90980–10214
B 3	Blower Motor Controller	90980–11667
B 4	Blower Motor Controller	90980–11579
B 5	Body ECU	90980–12458
B 6	Body ECU	90980–12329
B 7	Body ECU	90980–12150
B 8	Brake Pedal Stroke Sensor	90980–11150
B 9	Battery Blower Motor	90980–10916
B10	Battery Blower Motor Controller	90980–11676
B11	Battery ECU	90980–12203
B12	Battery ECU	90980–11915
B13	Battery ECU	90980–12155
B14	Battery Fan Relay	82660–20340
B15	Buckle SW (Driver's Side)	90980–11918
B16	Buckle SW (Driver's Side)	90980–10942
	Seat Position Airbag Sensor	

Code	Part Name	Part Number
B17	Buckle SW (Front Passenger's Side)	90980–11918
B18	Brake Master Stroke Simulator Cylinder Assembly	90980–11003
B19	Brake Control Power Supply	82824–50190
C 1	Camshaft Position Sensor	90980–10947
C 2	Camshaft Timing Oil Control Valve	90980–11162
C 3	Circuit Breaker Sensor	90980–11898
C 4	Compressor Assembly (Motor)	–
C 5	Converter	90980–11034
C 6	Converter	90980–11963
C 7	Crankshaft Position Sensor	90980–12028
C 8	Center Speaker	90980–10860
C 9	Clock	90980–11013
C10	Combination Meter	90980–12153
C11	Combination SW	90980–12266
C12	Combination SW	90980–12265
C13	Combination SW	90980–12358
C14	Combination SW	90980–12359
C15	Curtain Shield Airbag Sensor LH	90980–12241
C16	Curtain Shield Airbag Sensor RH	
C17	Curtain Shield Airbag Squib LH	90980–12219
C18	Curtain Shield Airbag Squib RH	
D 1	DLC3	90980–11665
D 2	Door Control Receiver	90980–12366
D 3	Door Courtesy Light (Driver's Side)	90980–11148
D 4	Door Courtesy Light (Front Passenger's Side)	
D 5	Door Courtesy SW (Driver's Side)	90980–10871
D 6	Door Courtesy SW (Front Passenger's Side)	
D 7	Door Courtesy SW Rear LH	
D 8	Door Courtesy SW Rear RH	
D 9	Door Key Lock and Unlock SW (Driver's Side)	90980–12226
	Door Lock Motor (Driver's Side)	
	Door Unlock Detection SW (Driver's Side)	
	Double Lock Motor (Driver's Side)	
	Double Lock Position SW (Driver's Side)	
D10	Door Lock Motor (Driver's Side)	
	Door Unlock Detection SW (Driver's Side)	
D11	Door Lock Motor (Front Passenger's Side)	
	Door Unlock Detection SW (Front Passenger's Side)	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
D12	Door Lock Motor (Front Passenger's Side)	90980–12226
	Door Unlock Detection SW (Front Passenger's Side)	
	Double Lock Motor (Front Passenger's Side)	
	Double Lock Position SW (Front Passenger's Side)	
D13	Door Lock Motor Rear LH	90980–12226
	Door Unlock Detection SW Rear LH	
D14	Door Lock Motor Rear LH	90980–12226
	Door Unlock Detection SW Rear LH	
	Double Lock Motor Rear LH	
	Double Lock Position SW Rear LH	
D15	Door Lock Motor Rear RH	90980–12226
	Door Unlock Detection SW Rear RH	
D16	Door Lock Motor Rear RH	90980–12226
	Door Unlock Detection SW Rear RH	
	Double Lock Motor Rear RH	
	Double Lock Position SW Rear RH	
D17	Door Oscillator (Driver's Side w/ Sensor)	90980–12217
D18	Door Oscillator (Front Passenger's Side w/ Sensor)	
E 1	EFI Water Temp. Sensor	90980–10735
E 2	Engine Hood Courtesy SW	90980–11003
E 3	Engine ECU	90980–12144
E 4	Engine ECU	90980–12145
E 5	Engine ECU	90980–12146
E 6	Engine ECU	90980–12142
E 7	Electrical Key Antenna (Driver's Side)	90980–12382
E 8	Electrical Key Antenna (Front Passenger's Side)	
E 9	Electrical Key Antenna (Luggage Compartment Door)	90980–10824
F 1	Front Clearance Light LH	90980–11156
F 2	Front Clearance Light RH	
F 3	Front Fog Light LH	90980–11096
F 4	Front Fog Light RH	
F 5	Front Side Turn Signal Light LH	90980–11162
F 6	Front Side Turn Signal Light RH	
F 7	Front Turn Signal Light LH	90980–11019
F 8	Front Turn Signal Light RH	
F 9	Front Washer Motor	
F10	Front Wiper Motor	90980–11599
F11	Front Passenger Seat Belt Warning Light	90980–12012
F12	Front Door Speaker LH	90980–10935
F13	Front Door Speaker RH	
F14	Fuel Pump	90980–11077
	Fuel Sender	

Code	Part Name	Part Number
F15	Fusible Link Block	90980–11775
F16	Fusible Link Block	90980–10916
F17	Fuse Holder	82610–20080
G 1	Gateway ECU	90980–12404
G 2	Glove Box Light	90980–11918
H 1	Headlight Beam Level Control Actuator LH	90980–11016
H 2	Headlight Beam Level Control Actuator RH	
H 3	Headlight LH	90980–11314
H 4	Headlight RH	
H 5	Horn (High)	90980–10619
H 6	Horn (Low)	
H 7	Hazard SW	90980–12091
	ODO/TRIP SW	
	Rheostat	
H 8	Headlight Beam Level Control SW	90980–10996
H 9	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980–11028
H10	Hybrid Vehicle Control ECU	90980–12431
H11	Hybrid Vehicle Control ECU	90980–12429
H12	Hybrid Vehicle Control ECU	90980–12428
H13	Hybrid Vehicle Control ECU	90980–12430
H14	High Mounted Stop Light	90980–11967
H15	Hybrid Vehicle Battery	82675–47060
H16	Hybrid Vehicle Battery	82675–47070
I 1	Ignition Coil and Igniter No.1	90980–11885
I 2	Ignition Coil and Igniter No.2	
I 3	Ignition Coil and Igniter No.3	
I 4	Ignition Coil and Igniter No.4	
I 5	Injector No.1	90980–11875
I 6	Injector No.2	
I 7	Injector No.3	
I 8	Injector No.4	
I 9	Inverter	90980–11148
I10	Inverter	90980–12153
I11	Inverter	90980–10988
I12	Inverter	90980–12465
I13	Inverter	90980–12464
I14	Inverter	90980–12434
I15	Inverter	90980–12433
I16	Inverter	90980–11147
I17	Inter Lock SW	90980–11918
I18	Interior Light	81366–68010
J 1	Junction Connector	90980–10803
J 2	Junction Connector	
J 3	Junction Connector	
J 4	Junction Connector	

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
J 5	Junction Connector	90980–10830
J 6	Junction Connector	90980–10803
J 7	Junction Connector	90980–11661
J 8	Junction Connector	
J 9	Junction Connector	90980–11915
J10	Junction Connector	
J11	Junction Connector	90980–10803
J12	Junction Connector	90980–11661
J13	Junction Connector	
J14	Junction Connector	90980–11915
J15	Junction Connector	
J16	Junction Connector	90980–10803
J17	Junction Connector	
J18	Junction Connector	90980–11915
J19	Junction Connector	
J20	Junction Connector	90980–11661
J21	Junction Connector	
J22	Junction Connector	90980–10803
J23	Junction Connector	
J24	Junction Connector	
J25	Junction Connector	
J26	Junction Connector	
J27	Junction Connector	90980–11529
J28	Junction Connector	
J29	Junction Connector	
J30	Junction Connector	
J31	Junction Connector	90980–10803
J32	Junction Connector	90980–11915
J33	Junction Connector	90980–10803
J34	Junction Connector	90980–11915
J35	Junction Connector	90980–10799
J36	Junction Connector	90980–11529
K 1	Knock Sensor	90980–11875
K 2	Key Slot	90980–12366
K 3	Key Slot	90980–12092
L 1	License Plate Light LH	90980–11148
L 2	License Plate Light RH	
L 3	Luggage Compartment Door Courtesy SW	90980–10795
	Luggage Compartment Door Opener Motor	
L 4	Luggage Compartment Door Lock SW	90980–12212
	Luggage Compartment Door Opener SW	
L 5	Luggage Compartment Light	90980–10860
L 6	Luggage Oscillator (Inner)	90980–12366
L 7	Luggage Oscillator (Outer)	90980–12217
M 1	Motor Generator No.1	90980–12432
M 2	Motor Generator No.1	

Code	Part Name	Part Number
M 3	Motor Generator No.1	90980–12432
M 4	Motor Generator No.1	90980–11034
M 5	Motor Generator No.2	90980–12432
M 6	Motor Generator No.2	
M 7	Motor Generator No.2	
M 8	Motor Generator No.2	90980–11034
M 9	Motor Generator No.2	
M10	Main SW	90980–11986
M11	Mirror Heater Relay	82660–20340
M12	Multi–Display	90980–12203
M13	Multi–Display	90980–12410
N 1	Noise Filter (Ignition)	90980–10843
N 2	Navigation ECU	90980–11973
N 3	Navigation ECU	90980–11923
N 4	Navigation ECU	90980–12221
N 5	Noise Filter (High Mounted Stop Light)	90980–10916
N 6	Noise Filter (Rear Window Defogger)	
N 7	Noise Filter (Rear Window Defogger)	
O 1	Oil Pressure SW	90980–11363
O 2	Overhead J/B	90980–12183
P 1	Pressure SW	90980–10943
P 2	Panel Relay	82660–20340
P 3	Parking Brake SW	90980–10871
P 4	Pattern Select SW	90980–10964
P 5	Power Outlet No.1	90980–10760
P 6	Power Outlet No.2	
P 7	Power Outlet Relay	82660–20340
P 8	Power Source Control ECU	90980–12388
P 9	Power Steering ECU	90980–12300
P10	Power Steering ECU	90980–12290
P11	Power Steering Motor	90980–12299
P12	Power Steering Torque Sensor	90980–12221
P13	Power SW	90980–11989
P14	PTC Heater	90980–11136
P15	PTC Heater	90980–10903
P16	Power Window Control SW (Front Passenger's Side)	90980–10789
P17	Power Window Control SW Rear LH	
P18	Power Window Control SW Rear RH	
P19	Power Window Master SW	90980–12122
P20	Power Window Motor (Driver's Side)	90980–10797
P21	Power Window Motor (Front Passenger's Side)	
P22	Power Window Motor Rear LH	
P23	Power Window Motor Rear RH	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
P24	Pretensioner LH	90980–12253
P25	Pretensioner RH	
R 1	Radiator Fan Motor	90980–10928
R 2	Rear Washer Motor	90980–11051
R 3	Radio and Player	90980–10997
R 4	Radio and Player	90980–10996
R 5	Radio and Player	90980–12259
R 6	Radio and Player	90980–12038
R 7	Room Oscillator	90980–12366
R 8	Rear Combination Light LH	90980–11011
R 9	Rear Combination Light RH	
R10	Rear Door Speaker LH	90980–10935
R11	Rear Door Speaker RH	
R12	Rear Window Defogger	90980–10914
R13	Rear Window Defogger	90980–10913
R14	Rear Window Defogger	90980–10914
R15	Rear Window Defogger	90980–10913
R16	Rear Wiper Motor	90980–10795
R17	Rear Wiper Relay	90980–10797
R18	Remote Control Mirror LH	90980–12189
R19	Remote Control Mirror RH	
R20	Remote Control Mirror SW	90980–11657
S 1	Shift Control Actuator	90980–12446
S 2	Short Connector	90980–11002
S 3	Short Connector	90980–11003
S 4	Shift Lever Position Sensor	90980–11989
S 5	Shift Lever Position Sensor	90980–12303
S 6	Skid Control Buzzer	90980–10906
S 7	Skid Control ECU	90980–12144
S 8	Skid Control ECU	90980–12145
S 9	Skid Control ECU	90980–12146
S10	Skid Control ECU	90980–12142
S11	Smart Key ECU	90980–12388
S12	Smart Key System Cancel SW	90980–10825
S13	Steering Sensor	90980–12162

Code	Part Name	Part Number
S14	Stereo Component Amplifier	90980–10821
S15	Stereo Component Amplifier	90980–12200
S16	Stop Light SW	90980–11118
S17	Side Airbag Sensor LH	90980–12241
S18	Side Airbag Sensor RH	
S19	Side Airbag Squib LH	90980–11864
S20	Side Airbag Squib RH	
S21	System Main Relay	90980–10795
S22	System Main Relay	90980–09938
S23	System Main Relay	
S24	System Main Relay	82675–28380
S25	System Main Relay	
S26	Short Connector (Water Pump)	90980–11162
S27	Short Connector (Water Pump)	90980–11168
T 1	Throttle Control Motor	90980–11162
T 2	Throttle Position Sensor	90980–10711
T 3	Theft Deterrent ECU	90980–12169
T 4	Theft Warning Sensor SW	90980–10860
T 5	Transmission Control ECU	90980–12203
T 6	Transponder Key Computer	90980–12404
T 7	Theft Deterrent Siren	90980–11349
T 8	Tweeter Front LH	90980–12304
T 9	Tweeter Front RH	
T10	Tweeter Rear LH	
T11	Tweeter Rear RH	
V 1	VSV (EVAP)	90980–11156
V 2	Vanity Light LH	90980–10935
V 3	Vanity Light RH	
V 4	Vanity Light SW LH	90980–11918
V 5	Vanity Light SW RH	
W 1	Water Pump Motor (A/C)	90980–10887
W 2	Water Pump Motor (Inverter)	90980–11162
W 3	Water Temp. SW	90980–11235
W 4	Wireless Door Lock Buzzer	90980–11142
Y 1	Yaw Rate Sensor	90980–11904