031VJ–01

TORQUE SPECIFICATION

Part Tightened		N·m	kgf·cm	ft·lbf
Fuel deliver pipe sub–assy x Cylinder head sub–assy (See page 11–16)	Bolt A	19	194	14
	Bolt B	9.0	92	80 in.·lbf
Cylinder head cover sub–assy Cylinder head sub–assy		10	102	7
Ignition coil assy x Cylinder head cover sub–assy		9.0	92	80 in.·lbf
Engine wire x Cylinder head cover sub–assy (RHD steering position type)		9.0	92	80 in.·lbf
Brake master cylinder reservoir cover x Cylinder head cover sub–assy (LHD steering position type)		8.5	87	75 in.·lbf
Reservoir bracket x Body		8.5	87	75 in.·lbf
Brake master cylinder reservoir sub–assy x Reservoir bracket		8.5	87	75 in.·lbf
Cowl top panel sub–assy outer front x Body		6.4	65	57 in.·lbf
Charcoal canister assy x Fuel tank assy		6.0	61	53 in.·lbf
Fuel tank band sub–assy No. 1 RH x Body		39	400	29
Fuel tank band sub–assy No. 1 LH x Body		39	400	29
Fuel tank protector No. 1 x Fuel tank assy		5.4	55	48 in.·lbf
Exhaust pipe assy front x Exhaust manifold		43	440	32
Exhaust pipe assy front x Exhaust pipe assy tail		43	440	32