
DTC	P0335	CRANKSHAFT POSITION SENSOR ”A” CIRCUIT

CIRCUIT DESCRIPTION

The crankshaft position sensor consists of a crankshaft position sensor plate and a pick–up coil.
The sensor plate has 34 teeth and is installed on the crankshaft. The pick–up coil is made of an iron core and magnet. The sensor plate rotates and as each tooth passes through the pick–up coil, a pulse signal is created. The pick–up coil generates 34 signals per engine revolution. Based on these signals, the ECM calculates the crankshaft position and engine RPM. Using these calculations, the fuel injection time and ignition timing are controlled.


DTC No.	DTC Detection Condition	Trouble Area
P0335	No crankshaft position sensor signal to ECM at engine speed of 600 rpm or more (2 trip detection logic)	• Open or short in crankshaft position sensor circuit • Crankshaft position sensor • Signal plate (crankshaft) • ECM



Reference: Inspection using an oscilloscope.
HINT:
The correct waveform is as shown on the left.

Item	Contents
Terminal	CH1: G2 – NE– CH2: NE+ – NE–
Equipment Setting	5 V/Division, 20 ms/Division
Condition	During cranking or idling

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

- If no trouble is found in the diagnostic troubleshooting procedure of DTC P0335, troubleshoot the engine mechanical systems.
- Read freeze frame data using the intelligent tester II. Freeze frame data records the engine condition when malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air–fuel ratio was lean or rich, and other data from the time the malfunction occurred.


- READ VALUE OF INTELLIGENT TESTER II
  (a) Connect the intelligent tester II to the DLC3.
  (b) Turn the power switch ON (IG).
  (c) Turn the intelligent tester II ON.
  (d) Put the engine in inspection mode (see page 05–1).
  (e) Start the engine.
  (f) On the intelligent tester II, select the item: Powertrain / Engine and ECT / Data List / Engine Speed.

The engine speed can be observed in DATA LIST using the intelligent tester II. If there is no NE signal from the crankshaft position sensor despite the engine revolving, the engine speed will be indicated as zero. If voltage output from the crankshaft position sensor is insufficient, the engine speed will be indicated as lower PRM (than the actual RPM).

1 INSPECT CRANKSHAFT POSITION SENSOR(RESISTANCE)

Component Side:

C7 Crankshaft Position Sensor



Front View

A78431

(a) Disconnect the C7 crankshaft position sensor connector.

(b) Measure the resistance between the terminals of the crankshaft position sensor connector.

Standard:

Tester Connection	Specified Condition
1 – 2	985 to 1,600 Ω at cold
1 – 2	1,265 to 1,890 Ω at hot

NOTICE:

Terms "cold" and "hot" refer to the temperature of the coils. "Cold" means approximately –10°C to 50°C (14°F to 122°F). "Hot" means approximately 50°C to 100°C (122°F to 212°F).

(c) Reconnect the crankshaft position sensor connector.


NG → **REPLACE CRANKSHAFT POSITION SENSOR (See page 18–10)**

OK

2 CHECK HARNESS AND CONNECTOR(CRANKSHAFT POSITION SENSOR – ECM)


Wire Harness Side:

Crankshaft Position Sensor Connector



Front View

A75251



ECM Connector

A65743

(a) Disconnect the C7 crankshaft position sensor connector.

(b) Disconnect the E3 ECM connector.

(c) Check the resistance between the wire harness side connectors.

Standard (Check for open):

Tester Connection	Specified Condition
NE+ (C7–1) – NE+ (E3–33)	Below 1 Ω
NE– (C7–2) – NE– (E3–34)	Below 1 Ω

Standard (Check for short):

Tester Connection	Specified Condition
NE+ (C7–1) or NE+ (E3–33) – Body ground	10 kΩ or higher
NE– (C7–2) or NE– (E3–34) – Body ground	10 kΩ or higher

(d) Reconnect the crankshaft position sensor connector.

(e) Reconnect the ECM connector.

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

3	CHECK SENSOR INSTALLATION(CRANKSHAFT POSITION SENSOR)

(a) Check that the crankshaft position sensor is properly installed.
OK: Sensor is installed correctly.

NG → **SECURELY REINSTALL SENSOR**

OK

4	CHECK CRANKSHAFT POSITION SENSOR PLATE(TEETH OF SENSOR PLATE(CRANKSHAFT))

(a) Check the teeth of the sensor plate.
OK: No deformation on the teeth of the signal plate.

NG → **REPLACE CRANKSHAFT POSITION SENSOR PLATE**

OK

REPLACE ECM (See page 10–24)