DTC P0A08/264 DC/DC CONVERTER STATUS CIRCUIT

CIRCUIT DESCRIPTION

Refer to DTC P0A09 (INF 265) on page 05–310.

DTC No.	INF Code	DTC Detection Condition	Trouble Area
P0A08	264	DC/DC converter malfunction	• w/ converter inverter assembly

INSPECTION PROCEDURE

When the HV control ECU detects an internal malfunction in the DC/DC converter, it sets DTC P0A08 (INF 264). If the information (INF) code is present, replace the w/ converter inverter assembly.

REPLACE W/ CONVERTER INVERTER ASSY (See page 21–25)