
HYBRID BATTERY SYSTEM

PRECAUTION

05IG5–01



1. Precautions for inspecting the hybrid battery system

(a) Before inspecting the high–voltage system, take safety precautions to prevent electrical shocks, such as wearing insulated gloves and removing the service plug grip (see page 01–5). After removing the service plug grip, put it in your pocket to prevent other technicians from reconnecting it while you are servicing the high–voltage system.

NOTICE:

Turning the power switch ON (READY) with the service plug grip removed could cause malfunction. Therefore, do not turn the power switch ON (READY) unless instructed by the repair manual.

(b) After disconnecting the service plug grip, wait at least for 5 minutes before touching any of high–voltage connectors or terminals.

HINT:

At least 5 minutes is required to discharge the high–voltage condenser inside the inverter.


(c) Since liquid leakage may occur, wear protective goggles when checking inside the HV battery.

(d) Wear insulated gloves, turn the power switch OFF, and disconnect the negative terminal of the auxiliary battery before touching any of the orange–colored wires of the high–voltage system.

(e) Turn the power switch OFF before performing a resistance check.

(f) Turn the power switch OFF before disconnecting or reconnecting any connector.

(g) To install this service plug grip, the lever must be flipped and locked downward. Once it is locked in place, it turns the interlock switch ON. Make sure to lock it securely because if you leave it unlocked, the system will output a DTC pertaining to the interlock switch system.



2. NOTICE FOR INITIALIZATION

When disconnecting the negative (–) battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See Page
Power Window Control System	05–1727

3. NOTICE FOR HYBRID SYSTEM ACTIVATION

- **When the warning lamp is illuminated or the battery has been disconnected and reconnected, pressing the power switch may not start the system on the first try. If so, press the power switch again.**
- **With the power switch's power mode changed to ON (IG), disconnect the battery. If the key is not in the key slot during reconnection, DTC B2799 may be output.**