05IGB–01

CHECK FOR INTERMITTENT PROBLEMS

1. CHECK FOR INTERMITTENT PROBLEMS

(a) Perform a simulation test (see page 01–36).

(1) In the simulation test, reproduce the driving condition at the trouble occurrence according to the customer's comments and freeze frame data recorded with DTCs.

(b) Check the connector(s) and terminal(s) (see page 01–46).

(c) Wiggle the harness and connector(s) (see page 01–46).