05IJX–01

PROBLEM SYMPTOMS TABLE

If there are no DTCs output but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

Symptoms	Suspect Areas	See page
ABS does not operate BA does not operate EBD does not operate	1. Check the DTC again and make sure that the normal code is output. 2. IG power source circuit and ground circuit. 3. Speed sensor circuit 4. Check the brake actuator with a intelligent tester II. (Check brake actuator operation using the active test function.) If abnormal, check the hydraulic circuit for leakage. 5. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05–738 05–782 05–754 05–761 32–62
ABS does not operate efficiently BA does not operate efficiently EBD does not operate efficiently	1. Check the DTC again and make sure that the normal code is output. 2. Speed sensor circuit 3. Stop lamp switch circuit 4. Check the brake actuator with a intelligent tester II. If abnormal, check the hydraulic circuit for leakage. 5. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05–738 05–754 05–761 05–804 32–62
ABS warning light abnormal	1. ABS warning light circuit 2. Skid control ECU	05–874 05–879 –
DTC of ABS check cannot be done	1. Check the DTC again and make sure that the normal code is output. 2. TC terminal circuit 3. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05–738 05–901
Sensor signal check cannot be done	1. TS terminal circuit 2. Skid control ECU	05–905 –
VSC does not operate	1. Check the DTC again and make sure that the normal code is output. 2. IG power source circuit and ground circuit. 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit 5. Yaw rate (deceleration) sensor circuit 6. Steering sensor circuit 7. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05–738 05–782 – 05–754 05–761 05–761 05–774
SLIP indicator light abnormal	1. SLIP indicator light circuit 2. Skid control ECU	05–893 –

Symptoms	Suspect Areas	See page
DTC of VSC check cannot be done	1. Check the DTC again and make sure that the normal code is output. 2. TC terminal circuit 3. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05–738 05–901
VSC warning light abnormal	1. Check the DTC again and make sure that the normal code is output. 2. VSC warning circuit 3. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05–738 05–880 or 05–885
Brake Control warning light abnormal	1. Check the DTC again and make sure that the normal code is output. 2. Brake Control warning circuit 3. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05–738 05–868 or 05–873