DTC C1300/– MALFUNCTION IN ECU

CIRCUIT DESCRIPTION

The skid control ECU outputs this DTC if malfunctions are found in the circuit inside the computer by self–diagnosis.

DTC No.	Detailed Code	DTC Detecting Condition	Trouble Area
C1300/–	–	Malfunction in skid control ECU	Skid control ECU

INSPECTION PROCEDURE

1	CHECK DTC

(a) Clear the DTCs (see page 05–738).
(b) Turn the power switch ON (READY).
(c) Check the same DTCs are recorded.
Result:

DTC is output	A
DTC is not output	B

B → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05–729)**

A

REPLACE SKID CONTROL ECU ASSY (SEE PAGE 32–81 or 32–82)

NOTICE:
When replacing the skid control ECU assy, perform initialization of linear solenoid valve and calibration (see page 05–721).