BRAKE CONTROL WARNING LIGHT CIRCUIT (DOES NOT LIGHT UP)

INSPECTION PROCEDURE

1	INSPECT CAN COMMUNICATION SYSTEM (SEE PAGE 05–2315)

(a) Is the DTC output for CAN communication system?

Result:

DTC is not output	A
DTC is output	B

B → REPAIR CAN COMMUNICATION SYSTEM (SEE PAGE 05–2332)

A

2	INSPECT MULTIPLEX COMMUNICATION SYSTEM (SEE PAGE 05–2250)

(a) Is the DTC output for Multiplex communication system?

Result:

DTC is not output	A
DTC is output	B

B → REPAIR MULTIPLEX COMMUNICATION SYSTEM (SEE PAGE 05–2261)

A

REPAIR OR REPLACE COMBINATION METER ASSY (SEE PAGE 05–1584)