05IM5–02

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
P position switch indicator light does not come on.	1. P position switch indicator light circuit 2. Transmission control ECU assy	05–969 –
P position switch indicator light does not go off.	1. P position switch indicator light circuit 2. Transmission control ECU assy	05–969 –