050YH–24

PROBLEM SYMPTOMS TABLE

HINT:

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
• When the power switch is on (IG), the SRS warning light sometimes comes on after approximately 6 seconds. • The SRS warning light remains on when DTC is not output.	• SRS Warning Light Circuit Malfunction (Remains on when DTC is not output)	05–1439
• The SRS warning light does not come on with the power switch on (IG).	• SRS Warning Light Circuit Malfunction (Does not come on when the power switch is turned on (IG)).	05–1445
• SRS warning light is blink. • DTC cannot read.	• TC Terminal Circuit	05–1447