DTC	B1908	SHORT IN P/T SQUIB (P SEAT SIDE) CIRCUIT (TO B+)

CIRCUIT DESCRIPTION

The P/T squib (P seat side) circuit consists of the airbag ECU assy and the front seat outer belt assy RH (LHD) or front seat outer belt assy LH (RHD).
This circuit instructs the SRS to deploy when deployment conditions are met.
DTC B1908 is recorded when a short to B+ circuit is detected in the P/T squib (P seat side) circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1908	• When the airbag sensor assy center receives a B+ short signal in the P/T squib (P seat side) circuit for 0.5 seconds. • P/T squib (P seat side) malfunction • Airbag ECU assy malfunction	• Floor wire No.2 • Front seat outer belt assy RH (LHD) (P/T squib (P seat side)) • Front seat outer belt assy LH (RHD) (P/T squib (P seat side)) • Airbag ECU assy

WIRING DIAGRAM

See page 05–1418.


INSPECTION PROCEDURE

CAUTION:

Be sure to perform the following procedures before troubleshooting to avoid unexpected airbag deployment.

(a) Turn the power switch off.
(b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
(c) Disconnect the connectors from the airbag sensor assy center.
(d) Disconnect the connectors from the horn button assy.
(e) Disconnect the connectors from the front passenger airbag assy.
(f) Disconnect the connector from the front seat airbag assy LH.
(g) Disconnect the connector from the front seat airbag assy RH.
(h) Disconnect the connector from the curtain shield airbag assy LH.
(i) Disconnect the connector from the curtain shield airbag assy RH.
(j) Disconnect the connector from the front seat outer belt assy LH.
(k) Disconnect the connector from the front seat outer belt assy RH.


1	CHECK FLOOR WIRE NO.2(P/T SQUIB (P SEAT SIDE) CIRCUIT)



(a) LHD:
(1) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
(2) Turn the power switch on (IG).
(3) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
P25–1 (R+) – Body ground	Power switch is on (IG)	Below 1 V
P25–2 (R–) – Body ground	Power switch is on (IG)	Below 1 V



(b) RHD:
(1) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
(2) Turn the power switch on (IG).
(3) Measure the voltage according to the value(s) in the table below.


Standard:


Tester connection	Condition	Specified condition
P24–1 (L+) – Body ground	Power switch is on (IG)	Below 1 V
P24–2 (L–) – Body ground	Power switch is on (IG)	Below 1 V

NG → **REPAIR OR REPLACE FLOOR WIRE NO.2**

OK

2 CHECK AIR BAG ECU ASSY





(a) Turn the power switch off.

(b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.

(c) Connect the connectors to the airbag ECU assy.

(d) LHD:
Using a service wire, connect P25–1 (R+) and P25–2 (R–) of connector "C".

(e) RHD:
Using a service wire, connect P24–1 (L+) and P24–2 (L–) of connector "C".

NOTICE:

- **Twist the end of the service wire in order to insert it into the connector.**
- **Do not forcibly insert the twisted service wire into the terminals of the connector when connecting.**

(f) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.

(g) Turn the power switch on (IG), and wait for at least 60 seconds.

(h) Clear the DTCs stored in memory (see page 05–1170).

(i) Turn the power switch off.

(j) Turn the power switch on (IG), and wait for at least 60 seconds.

(k) Check the DTCs (see page 05–1170).

OK:

DTC B1908 is not output.


HINT:

Codes other than code B1908 may be output at this time, but they are not related to this check.

NG	**REPLACE AIR BAG ECU ASSY (SEE PAGE 60–54)**

OK

3	CHECK DTC (P/T SQUIB (P SEAT SIDE))



(a) Turn the power switch off.
(b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
(c) Disconnect the service wire from connector "C".
(d) LHD:
Connect the connector to the front seat outer belt assy RH.
(e) RHD:
Connect the connector to the front seat outer belt assy LH.
(f) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
(g) Turn the power switch on (IG), and wait for at least 60 seconds.
(h) Clear the DTCs stored in memory (see page 05–1170).
(i) Turn the power switch off.
(j) Turn the power switch on (IG), and wait for at least 60 seconds.
(k) Check the DTCs (see page 05–1170).

Result:

DTC B1908 is not output.	A
DTC B1908 is output (LHD).	B
DTC B1908 is output (RHD).	C

HINT:
Codes other than code B1908 may be output at this time, but they are not related to this check.

B	**REPLACE FRONT SEAT OUTER BELT ASSY RH (SEE PAGE 61–10)**
C	**REPLACE FRONT SEAT OUTER BELT ASSY LH (SEE PAGE 61–10)**

A

USE SIMULATION METHOD TO CHECK (SEE PAGE 05–1165)

HINT:
- Perform the simulation method by selecting the check mode with the intelligent tester II (see page 05–1171).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05–1171).