BLACK SCREEN (NO IMAGE APPEARS ON NAVIGATION AND AUDIO SCREEN)

INSPECTION PROCEDURE

1	CHECK DISPLAY SETTING

(a) Check that the display is not in "Screen OFF" mode.
OK: The display setting is not in "Screen OFF" mode.

NG → CHANGE SCREEN TO "SCREEN ON" MODE

OK

2	CHECK IMAGE QUALITY SETTING

(a) Check if screen color quality can be set.
OK: Switching is possible.

OK → PRESS PANEL SWITCH "DISPLAY" AND SET SCREEN COLOR QUALITY TO NORMAL

NG

3	CHECK CABIN

(a) Check if condensation is likely to occur, or the temperature is high or low (extremely cold) in the cabin.
HINT:
This problem occurs when the cabin is humid and the temperature rapidly changes. This condition may produce condensation, resulting in a short circuit.
OK: The above condition is not observed.

NG → SET CABIN TEMPERATURE TO APPROPRIATE DEGREES

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1570)