THE CELLULAR PHONE CANNOT SEND/RECEIVE

INSPECTION PROCEDURE

1	CHECK THE BLUETOOTH SETTINGS

(a) Check if the BLUETOOTH settings are correct.
OK: BLUETOOTH settings are correct.

NG → **SET SETTINGS CORRECTLY**

OK

2	CHECK CELLULAR PHONE

(a) Check if the cellular phone is BLUETOOTH capable.
HINT:
Some versions of BLUETOOTH capable cellular phone may not be compatible.
OK: The phone is BLUETOOTH capable.

NG → **END (ONLY A BLUETOOTH CAPABLE CELLULAR PHONE CAN BE USED)**

OK

3	CHECK SETTINGS

(a) Check if the cellular phone functions.
HINT:
- The cellular phone is unable to call under any of the following conditions.
- The cellular phone is locked.
- The directory is being transferred.
- The line is crossed.
- Transmission is regulated.
- The power is off.
- An emergency call is being made (LEXUS LINK SYSTEM is in operation).
- The cellular phone is not connected to BLUETOOTH (”BT” is displayed while a connection is present).

OK: None of the above conditions exists.

NG → **SET SETTINGS CORRECTLY**

OK

4	CHECK CELLULAR PHONE

(a) Check if the cellular phone can call.

HINT:

When the battery charge is low, calls cannot be made or received.

OK: The cellular phone can call.

NG → **REPLACE THE CELLULAR PHONE**

OK ↓

5	CHECK RECEPTION

(a) Put a cellular phone into a receiving state.

(b) Place the cellular phone close to the multi–display.

(c) Check if the cellular phone has reception according to the multi–display.

OK: The cellular phone has reception.

NG → **REPLACE MULTI–DISPLAY (SEE PAGE 67–7)**

OK ↓

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05–1570)