05IAJ–01

CUSTOMIZE PARAMETERS

1. BUZZER CANCEL SETTING

(a) Check that the ODO display is on, and turn the power switch off and then on. If other display is on, change it to the ODO display.

(b) Within 6 seconds, push and hold the ODO/TRIP switch for 10 seconds or more.

(c) Following the table below, set the buzzer cancel setting.

Buzzer	Operation
Seat belt buzzers for driver's seat	Driver's seat buckle switch OFF → ON (Seat belt unfastened → fastened)
Seat belt buzzer for passenger seat	Passenger seat buckle switch OFF → ON (Seat belt unfastened → fastened)

HINT:

The ODO/TRIP display changes from "b–on" to "b–off", entering the cancel mode.

(d) During the cancel mode, each time the ODO/TRIP switch is pushed, the setting is switched between*1 b–on and *2 b–off.

HINT:

*1 b–on: Cancel is invalid

*2 b–off: Cancel is valid

(e) After the setting, the mode will be canceled by either not operating the switch for 10 seconds or more, or turning the power switch from on to off.

HINT:

The setting can be reset when reconnecting the battery connector or removing/installing the meter connector(Buzzer on).