05IDB–01

PROBLEM SYMPTOMS TABLE

Symptoms	Suspected Area	See Page
AUTO UP/DOWN function does not operate	1. Power window regulator motor assy (driver side) 2. Wire harness 3. Power window regulator master switch assy	05–1734
Remote UP/DOWN function does not operate	1. Power window regulator master switch assy 2. Wire harness	05–1737
Manual UP/DOWN function does not operate on driver side	1. FR DOOR fuse 2. Power window regulator master switch assy 3. Power window regulator motor assy (driver side) 4. Wire harness	05–1740
Manual UP/DOWN function does not operate on passenger side only	1. Power window regulator switch assy (passenger side) 2. Power window regulator motor assy (passenger side) 3. Wire harness	05–1743
Manual UP/DOWN function does not operate on rear LH side	1. Power window regulator switch assy (rear LH) 2. Power window regulator motor assy (rear LH) 3. Wire harness	05–1746
Manual UP/DOWN function does not operate on rear RH side	1. Power window regulator switch assy (rear RH) 2. Power window regulator motor assy (rear RH) 3. Wire harness	05–1749
Jam protection function does not operate	1. Power window regulator master switch assy	05–1762
Power windows do not operate at all	1. AM1 fuse 2. GAUGE fuse 3. POWER fuse 4. ECU–IG fuse 5. FR DOOR fuse 6. PWR relay 7. IG1 relay 8. Power window regulator master switch assy 9. Wire harness 10. Instrument panel J/B assy (Multiplex network body ECU)	05–1752
Power window can be operated after power switch's power mode is changed to OFF even when certain conditions are not met	1. Power window regulator master switch assy 2. Front door courtesy lamp switch 3. Wire harness 4. Multiplex network body ECU	05–1756
AUTO UP operation does not fully close power window (jam protection function is activated)	1. Front door window regulator assy 2. Power window regulator motor assy (driver side) 3. Power window regulator master switch assy	05–1760