JAM PROTECTION FUNCTION DOES NOT OPERATE

CIRCUIT DESCRIPTION

The power window regulator master switch assembly controls the driver side power window regulator motor. The jam protection function only operates within a specified range during AUTO UP operation or key–off manual UP operation.

HINT:

The jam protection function is only available on the driver side power window.

INSPECTION PROCEDURE

1	RESET POWER WINDOW REGULATOR MOTOR

(a) Reset the power window regulator motor (see page 05–1727).

(b) Check if the power window AUTO UP/DOWN function operates normally.

OK: AUTO UP/DOWN function operates normally.

NG → **OTHER PROBLEM (See page 05–1728)**

OK

2	CHECK JAM PROTECTION FUNCTION OPERATING RANGE

(a) Check that the jam protection function operates normally (see page 05–1763).

HINT:

The jam protection function does not operate from the fully closed position of the door glass to 4 mm (0.16 in.) below that.

NG → **REPLACE POWER WINDOW REGULATOR MASTER SWITCH ASSY**

OK

END