05IFD–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All doors lock/unlock functions do not operate via master switch	1. DOOR fuse 2. DOME fuse 3. Power window regulator master switch assy 4. Wire harness 5. Instrument panel J/B assy (Multiplex network body ECU)	05–1795
All doors lock/unlock functions do not operate via driver side door key cylinder	1. Driver door lock assy 2. Wire harness 3. Instrument panel J/B assy (Multiplex network body ECU)	05–1798
Only driver door lock/unlock functions do not operate	1. Driver door lock assy 2. Wire harness 3. Instrument panel J/B assy (Multiplex network body ECU)	05–1802
Only passenger door lock/unlock functions do not operate	1. Passenger door lock assy 2. Wire harness 3. Instrument panel J/B assy (Multiplex network body ECU)	05–1807
Only rear LH door lock/unlock functions do not operate	1. Rear door lock assy LH 2. Wire harness 3. Instrument panel J/B assy (Multiplex network body ECU)	05–1812
Only rear RH door lock/unlock functions do not operate	1. Rear door lock assy RH 2. Wire harness 3. Instrument panel J/B assy (Multiplex network body ECU)	05–1818
Only luggage door lock/unlock functions do not operate	1. Luggage compartment door lock assy 2. Luggage compartment door opener switch (w/o smart key system) 3. Luggage electrical key switch (w/ smart key system) 4. Wire harness 5. Instrument panel J/B assy (Multiplex network body ECU)	05–1824
Key lock–in prevention function does not work properly (manual operation and key–linked lock are activated)	1. Key slot 2. Front door courtesy lamp switch assy (Driver side) 3. Wire harness 4. Instrument panel J/B assy (Multiplex network body ECU)	05–1830
w/ Double lock system: Double lock function does not operate properly	1. DOOR fuse 2. Driver door lock assy 3. Passenger door lock assy 4. Rear door lock assy LH 5. Rear door lock assy RH 6. Wire harness 7. Instrument panel J/B assy (Multiplex network body ECU)	05–1835