05IB7-01

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- Use these procedures to troubleshoot the smart entry system.
- The intelligent tester II should be used in steps 3 and 5.

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05–1879)

3	INSPECT COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)

(a) Use the intelligent tester II to check for normal function of the multiplex communication system.
  (1) (ECU unconnected, communication stop, communication line malfunctioning)
  Without code outputs, proceed to A.
  (2) (ECU unconnected, communication stop, communication line malfunctioning)
  With code outputs, proceed to B.

B → Go to MULTIPLEX COMMUNICATION SECTION (See page 05–2261)

A

4	PROBLEM SYMPTOMS TABLE (See page 05–1882)

(a) If the fault is not listed on the problem symptoms table, proceed to A.
(b) If the fault is listed on the problem symptoms table, proceed to B.

B → Go to step 6

A

5	OVERALL ANALYSIS AND TROUBLESHOOTING

(a) On vehicle inspection (see page 05–1932)
(b) DATA LIST/ACTIVE TEST (see page 05–1889)
  (1) Inspection with the intelligent tester II (DATA LIST).
  (2) Inspection with the intelligent tester II (ACTIVE TEST).
(c) Terminals of ECU (see page 05–1883)

6	ADJUST, REPAIR OR REPLACEMENT

7	CONFIRMATION TEST

END