05IIN–01

DATA LIST/ACTIVE TEST

1. DATA LIST

HINT:

Using the intelligent tester II DATA LIST allows switch, actuator and other item values to be read without removing any parts. Reading the DATA LIST early in troubleshooting is one way to shorten labor time.

(a) Connect the intelligent tester II to the DLC3.

(b) Turn the power switch ON (IG).

(c) Read the DATA LIST according to display on the tester.

Transponder key ECU:

Item	Measurement Item/Display (Range)	Normal Condition	Diagnostic Note
Key Unlk Wrn SW	Halfway switch signal /ON or OFF	ON: Key is in key slot. OFF: No key is in key slot.	–

Multiplex network body ECU:

Item	Measurement Item/Display (Range)	Normal Condition	Diagnostic Note
D Dor Cty SW	Driver side door courtesy switch signal /ON or OFF	ON: Driver side door is open. OFF: Driver side door is closed.	–