05IIT–01

ON–VEHICLE INSPECTION

1. CHECK FUNCTION

(a) Check the key reminder warning buzzer sound function.
  (1) Close the driver side door, insert the key into the key slot and change the power switch's power mode to OFF by pressing the power switch.
  (2) Open the driver side door. Check that the key reminder warning buzzer emits sounds intermittently.

(b) Check that the key reminder warning buzzer stops.
  (1) While the buzzer is sounding, perform one of the following operations:
  - Close the driver side door (front door courtesy lamp switch is turned off).
  - Change the power switch's power mode to ON (IG) by pressing the power switch.
  - Pull out the key from the key slot.

  (2) Check that the key reminder warning buzzer stops sounding.